


CUT PCB FROM HERE IF
2 x 6 INPUT SELECTOR
IS NOT USED

REMEMBER TO PUT ALL JUMPERS
IN THEIR PLACES.



THERE ARE TWO DIFFERENT PCB :
2 x 6 INPUT SELECTOR AND
TONE CONTROL + SUBWOOFER OUT